ENGINE CONTROL, FUEL & EXHAUST SYSTEMS


SECTION FE

EXHAUST SYSTEM

With catalyst

CAUTION:

a. Be careful not to drop or damage catalytic converter.
b. Never wet catalytic converter with oil.



: N·m (kg-m, ft-lb)

SFE870